





## HIGH VOLTAGE PROBE

Model: HV-40

		SPECIFICATIONS
Attenuate Ratio	1:1000.	
Input Impedance	Арргох. 1000 М оhm.	
Output	Around 1	.1 M ohm. The input impedance of external voltmeter
Impedance	should be	10 mega ohm.
Max. Working	DCV	DC 40 KV
Voltage	ACV	Peak AC 40 KV or 28 KV rms
		( depend which values is larger ).
Accuracy	DCV	1 KV to 20 KV - ±1 %.
		20 KV to 40 KV - ±1.5 %.
	ACV	1 to 28 KV rms, 50/60 Hz - ±5 %.
Temp Coefficient	Less than 200 ppm/°C.	
Operating Temperature	0 °C to 50 °C (32 °F to 122 °F).	
Operating Humidity	Less than 80% RH.	
Cable Length	1 meter.	

## OPERATION

Connect the plugs to the volts (Hi) & com (Lo) input terminals of your voltmeter (or Multimeter). Select the desired range of voltmeter (Attention: Do not use autoranging). Whenever possible, turn the high voltage source off before making any connections. Connect the HV probe common lead (alligator clip) to a good earth ground or reliable chassis ground.

## SAFETY PRECAUTION & WARNING III

- \* This high voltage probe must be used by the person who are trained only. Do not work alone when working with high voltage circuits & environment.
- \* For your own safety, inspect the probes for cracks & frayed or broken leads before each use. If any defects are noted, do not use the probes.
- \* Hands, shoes, floor & work bench must be dry. Avoid making measurements under humid, damp or other environmental conditions that might affect the safety of measurement situation.
- \* The ground connection must always be made before the probe tip comes into contact with the high voltage & must not be removed until after the probe tip has been removed from high voltage source.
- \*Do not attempt to take measurement from sources where the chassis or return lead is not ground.
- \* If possible, always turn the high voltage source off before connecting or disconnecting the probe.
- \* Before turning the high voltage on, make sure that no part of your body is in contact with the device under test.
- \*The probe body should be kept clean & free of any conductive contamination. Clean only the exterior probe body & cables. Use a soft cotton cloth lightly moistened with a mild solution of detergent & water. Do not allow any portion of the probe to be submerged at any time.